

### **INSTRUCTION FOR TILE INSTALLATIONS**

1. Measure the exact distance from wall to wall and snap a chalk line, which divides the room into two equal sections.
2. The first row of blocks is to be installed dead center on the chalk line. (Please refer to the installation example)
3. It is imperative that the first row of blocks be installed in a perfect straight line. Failure to interlock all rows exactly parallel to previously installed rows will cause disengagement of the blocks.
4. These blocks require the sub-flooring on which they are to be installed to be horizontally level. If the sub-flooring is not level and smooth, the manufacturer recommends these be adhered to the sub-flooring with rubber latex cement.