



The Package

This is how you receive your product. We send a layout with each stall kit that shows exactly how to position the mats in the stall. All you have to do is make sure your subsurface is prepared correctly.



Humane mats can be placed over concrete, asphalt, wood or any level well-compacted surface. The gentlemen to the left are using decomposed granite, you can also use limestone fines, just make sure the fines do not exceed 1/8" in size. Fines are easy to work with, compact well, provide good drainage, and stand up to freeze/thaw conditions. The fines should be installed to a depth of 4 to 5 inches which may require excavating some of the existing material to maintain current stall elevations. Once you fill the stall base, use a 3/4" board (the thickness of our mats) to ensure you have the perfect the level for stall.



Once you have the correct amount of fines in the stall, level and tamp the fines. Use water to soak the material aiding in the compaction process.



Now that the subsurface is level and compacted, just let it dry and you are ready to install the mats. Use the stall diagram, the mats are marked on the bottom with numbers from the diagram. Start in one corner of the stall and fit pieces together like puzzle, once the interlock is started, you can walk over them to fit in place. Because rubber can expand and contract, we recommend you leave 1/4" to 1/2" between the edge of the mat and the stall wall.



The Finished Stall: now just a small amount of bedding, and your horse can enter its new home. You will spend less time mucking the stall and more time enjoying your horse.

