



ROUTINE CLEANING AND INSPECTION

Recycled Rubber Tiles should be visually inspected and cleaned on an established interval. The frequency will depend on the environment and level of use. **EMC recommends an inspection and cleaning interval of not greater than one time per month**.

CLEANING & MAINTENANCE

- a. Standard Cleaning & Maintenance Options:
 - 1. Sweep the surfacing with a stiff bristle outdoor broom to remove larger debris and accumulated dirt and dust.
 - 2. Spray the surfacing with clean water using a standard hose to remove contaminants from the surfacing as well as the pores of the system.
 - 3. Vacuum the surface with a commercial grade vacuum to remove loose particles from the surface, transitions, joints and pores of the system.
- b. Cleaning Stains
 - 1. Use a mild cleaning soap with a soft bristle brush or mop to scrub the affected area.
 - 2. Use clean water to thoroughly rinse any area covered with soap residue.
- c. Annual Maintenance Guidelines:
 - 1. Remove any debris or other loose material.
 - 2. Broom the entire surface of the system.
 - 3. Vacuum the entire surface of the system.
 - 4. Spray the surfacing with clean water.
 - 5. Use a mild cleaning soap with a soft bristle brush or mop and scrub the surface in 5 foot by 5 foot sections. Thoroughly spray the affected area with clean water to remove any soap residue.
 - 6. Continue cleaning with mild soap and water until the entire surfacing system has been cleaned.